

# Conversion table from the current design to the new design

## HighTorque Servo Gearbox $a=50$



Ratio	Output shaft	Current Order-No.	New Order-No. Basic Gerbox	New Order-No. Motor flange
4,75	ISO	98 43 105	98 03 005	65 59 301
	Clamp connect.	98 83 105	98 13 005	
	ISO	98 43 205	98 03 005	65 59 302
	Clamp connect.	98 83 205	98 13 005	
	ISO	98 43 305	98 03 005	65 59 303
	Clamp connect.	98 83 305	98 13 005	
	ISO	98 43 505	98 03 005	65 59 306
	Clamp connect.	98 83 505	98 13 005	
	ISO	98 43 805	98 03 005	65 59 304
	Clamp connect.	98 83 805	98 13 005	
ISO	98 43 905	98 03 005	65 59 402	
Clamp connect.	98 83 905	98 13 005		
6,75	ISO	98 43 107	98 03 007	65 59 301
	Clamp connect.	98 83 107	98 13 007	
	ISO	98 43 207	98 03 007	65 59 302
	Clamp connect.	98 83 207	98 13 007	
	ISO	98 43 307	98 03 007	65 59 303
	Clamp connect.	98 83 307	98 13 007	
	ISO	98 43 507	98 03 007	65 59 306
	Clamp connect.	98 83 507	98 13 007	
	ISO	98 43 807	98 03 007	65 59 304
	Clamp connect.	98 83 807	98 13 007	
ISO	98 43 907	98 03 007	65 59 402	
Clamp connect.	98 83 907	98 13 007		
9,25	ISO	98 43 109	98 03 009	65 59 301
	Clamp connect.	98 83 109	98 13 009	
	ISO	98 43 209	98 03 009	65 59 302
	Clamp connect.	98 83 209	98 13 009	
	ISO	98 43 309	98 03 009	65 59 303
	Clamp connect.	98 83 309	98 13 009	
	ISO	98 43 509	98 03 009	65 59 306
	Clamp connect.	98 83 509	98 13 009	
	ISO	98 43 809	98 03 009	65 59 304
	Clamp connect.	98 83 809	98 13 009	
ISO	98 43 909	98 03 009	65 59 402	
Clamp connect.	98 83 909	98 13 009		
14,5	ISO	98 43 115	98 03 015	65 59 301
	Clamp connect.	98 83 115	98 13 015	
	ISO	98 43 215	98 03 015	65 59 302
	Clamp connect.	98 83 215	98 13 015	
	ISO	98 43 315	98 03 015	65 59 303
	Clamp connect.	98 83 315	98 13 015	
	ISO	98 43 515	98 03 015	65 59 306
	Clamp connect.	98 83 515	98 13 015	
	ISO	98 43 815	98 03 015	65 59 304
	Clamp connect.	98 83 815	98 13 015	
ISO	98 43 915	98 03 015	65 59 402	
Clamp connect.	98 83 915	98 13 015		

Ratio	Output shaft	Current Order-No.	New Order-No. Basic Gerbox	New Order-No. Motor flange
19,5	ISO	98 43 120	98 03 020	65 59 301
	Clamp connect.	98 83 120	98 13 020	
	ISO	98 43 220	98 03 020	65 59 302
	Clamp connect.	98 83 220	98 13 020	
	ISO	98 43 320	98 03 020	65 59 303
	Clamp connect.	98 83 320	98 13 020	
	ISO	98 43 520	98 03 020	65 59 306
	Clamp connect.	98 83 520	98 13 020	
	ISO	98 43 820	98 03 020	65 59 304
	Clamp connect.	98 83 820	98 13 020	
ISO	98 43 920	98 03 020	65 59 402	
Clamp connect.	98 83 920	98 13 020		
29	ISO	98 43 129	98 03 029	65 59 301
	Clamp connect.	98 83 129	98 13 029	
	ISO	98 43 229	98 03 029	65 59 302
	Clamp connect.	98 83 229	98 13 029	
	ISO	98 43 329	98 03 029	65 59 303
	Clamp connect.	98 83 329	98 13 029	
	ISO	98 43 529	98 03 029	65 59 306
	Clamp connect.	98 83 529	98 13 029	
	ISO	98 43 829	98 03 029	65 59 304
	Clamp connect.	98 83 829	98 13 029	
ISO	98 43 929	98 03 029	65 59 402	
Clamp connect.	98 83 929	98 13 029		
39	ISO	98 43 139	98 03 039	65 59 301
	Clamp connect.	98 83 139	98 13 039	
	ISO	98 43 239	98 03 039	65 59 302
	Clamp connect.	98 83 239	98 13 039	
	ISO	98 43 339	98 03 039	65 59 303
	Clamp connect.	98 83 339	98 13 039	
	ISO	98 43 539	98 03 039	65 59 306
	Clamp connect.	98 83 539	98 13 039	
	ISO	98 43 839	98 03 039	65 59 304
	Clamp connect.	98 83 839	98 13 039	
ISO	98 43 939	98 03 039	65 59 402	
Clamp connect.	98 83 939	98 13 039		
50	ISO	98 43 150	98 03 050	65 59 301
	Clamp connect.	98 83 150	98 13 050	
	ISO	98 43 250	98 03 050	65 59 302
	Clamp connect.	98 83 250	98 13 050	
	ISO	98 43 350	98 03 050	65 59 303
	Clamp connect.	98 83 350	98 13 050	
	ISO	98 43 550	98 03 050	65 59 306
	Clamp connect.	98 83 550	98 13 050	
	ISO	98 43 850	98 03 050	65 59 304
	Clamp connect.	98 83 850	98 13 050	
ISO	98 43 950	98 03 050	65 59 402	
Clamp connect.	98 83 950	98 13 050		

# Conversion table from the current design to the new design

## HighTorque Servo Gearbox a=63



Ratio	Output shaft	Current Order-No.	New Order-No. Basic Gerbox	New Order-No. Motor flange
4,75	ISO	98 44 005	98 04 005	65 59 406
	Klemmverb.	98 84 005	98 14 005	
	ISO	98 44 105	98 04 005	65 59 401
	Klemmverb.	98 84 105	98 14 005	
	ISO	98 44 205	98 04 005	65 59 407
	Klemmverb.	98 84 205	98 14 005	
	ISO	98 44 305	98 04 005	65 59 403
	Klemmverb.	98 84 305	98 14 005	
	ISO	98 44 505	98 04 005	65 59 404
	Klemmverb.	98 84 505	98 14 005	
	ISO	98 44 605	98 04 005	65 59 402
	Klemmverb.	98 84 605	98 14 005	
	ISO	98 44 705	98 04 005	65 59 409
	Klemmverb.	98 84 705	98 14 005	
ISO	98 44 905	98 04 005	65 59 406 und	
Klemmverb.	98 84 905	98 14 005	2 65 25 099	

Ratio	Output shaft	Current Order-No.	New Order-No. Basic Gerbox	New Order-No. Motor flange
19,5	ISO	98 44 020	98 04 020	65 59 406
	Klemmverb.	98 84 020	98 14 020	
	ISO	98 44 120	98 04 020	65 59 401
	Klemmverb.	98 84 120	98 14 020	
	ISO	98 44 220	98 04 020	65 59 407
	Klemmverb.	98 84 220	98 14 020	
	ISO	98 44 320	98 04 020	65 59 403
	Klemmverb.	98 84 320	98 14 020	
	ISO	98 44 520	98 04 020	65 59 404
	Klemmverb.	98 84 520	98 14 020	
	ISO	98 44 620	98 04 020	65 59 402
	Klemmverb.	98 84 620	98 14 020	
	ISO	98 44 720	98 04 020	65 59 409
	Klemmverb.	98 84 720	98 14 020	
ISO	98 44 920	98 04 020	65 59 406 und	
Klemmverb.	98 84 920	98 14 020	2 65 25 099	

6,75	ISO	98 44 007	98 04 007	65 59 406
	Klemmverb.	98 84 007	98 14 007	
	ISO	98 44 107	98 04 007	65 59 401
	Klemmverb.	98 84 107	98 14 007	
	ISO	98 44 207	98 04 007	65 59 407
	Klemmverb.	98 84 207	98 14 007	
	ISO	98 44 307	98 04 007	65 59 403
	Klemmverb.	98 84 307	98 14 007	
	ISO	98 44 507	98 04 007	65 59 404
	Klemmverb.	98 84 507	98 14 007	
	ISO	98 44 607	98 04 007	65 59 402
	Klemmverb.	98 84 607	98 14 007	
	ISO	98 44 707	98 04 007	65 59 409
	Klemmverb.	98 84 707	98 14 007	
ISO	98 44 907	98 04 007	65 59 406 und	
Klemmverb.	98 84 907	98 14 007	2 65 25 099	

29	ISO	98 44 029	98 04 029	65 59 406
	Klemmverb.	98 84 029	98 14 029	
	ISO	98 44 129	98 04 029	65 59 401
	Klemmverb.	98 84 129	98 14 029	
	ISO	98 44 229	98 04 029	65 59 407
	Klemmverb.	98 84 229	98 14 029	
	ISO	98 44 329	98 04 029	65 59 403
	Klemmverb.	98 84 329	98 14 029	
	ISO	98 44 529	98 04 029	65 59 404
	Klemmverb.	98 84 529	98 14 029	
	ISO	98 44 629	98 04 029	65 59 402
	Klemmverb.	98 84 629	98 14 029	
	ISO	98 44 729	98 04 029	65 59 409
	Klemmverb.	98 84 729	98 14 029	
ISO	98 44 929	98 04 029	65 59 406 und	
Klemmverb.	98 84 929	98 14 029	2 65 25 099	

9,25	ISO	98 44 009	98 04 009	65 59 406
	Klemmverb.	98 84 009	98 14 009	
	ISO	98 44 109	98 04 009	65 59 401
	Klemmverb.	98 84 109	98 14 009	
	ISO	98 44 209	98 04 009	65 59 407
	Klemmverb.	98 84 209	98 14 009	
	ISO	98 44 309	98 04 009	65 59 403
	Klemmverb.	98 84 309	98 14 009	
	ISO	98 44 509	98 04 009	65 59 404
	Klemmverb.	98 84 509	98 14 009	
	ISO	98 44 609	98 04 009	65 59 402
	Klemmverb.	98 84 609	98 14 009	
	ISO	98 44 709	98 04 009	65 59 409
	Klemmverb.	98 84 709	98 14 009	
ISO	98 44 909	98 04 009	65 59 406 und	
Klemmverb.	98 84 909	98 14 009	2 65 25 099	

39	ISO	98 44 039	98 04 039	65 59 406
	Klemmverb.	98 84 039	98 14 039	
	ISO	98 44 139	98 04 039	65 59 401
	Klemmverb.	98 84 139	98 14 039	
	ISO	98 44 239	98 04 039	65 59 407
	Klemmverb.	98 84 239	98 14 039	
	ISO	98 44 339	98 04 039	65 59 403
	Klemmverb.	98 84 339	98 14 039	
	ISO	98 44 539	98 04 039	65 59 404
	Klemmverb.	98 84 539	98 14 039	
	ISO	98 44 639	98 04 039	65 59 402
	Klemmverb.	98 84 639	98 14 039	
	ISO	98 44 739	98 04 039	65 59 409
	Klemmverb.	98 84 739	98 14 039	
ISO	98 44 939	98 04 039	65 59 406 und	
Klemmverb.	98 84 939	98 14 039	2 65 25 099	

14,5	ISO	98 44 015	98 04 015	65 59 406
	Klemmverb.	98 84 015	98 14 015	
	ISO	98 44 115	98 04 015	65 59 401
	Klemmverb.	98 84 115	98 14 015	
	ISO	98 44 215	98 04 015	65 59 407
	Klemmverb.	98 84 215	98 14 015	
	ISO	98 44 315	98 04 015	65 59 403
	Klemmverb.	98 84 315	98 14 015	
	ISO	98 44 515	98 04 015	65 59 404
	Klemmverb.	98 84 515	98 14 015	
	ISO	98 44 615	98 04 015	65 59 402
	Klemmverb.	98 84 615	98 14 015	
	ISO	98 44 715	98 04 015	65 59 409
	Klemmverb.	98 84 715	98 14 015	
ISO	98 44 915	98 04 015	65 59 406 und	
Klemmverb.	98 84 915	98 14 015	2 65 25 099	

52	ISO	98 44 052	98 04 052	65 59 406
	Klemmverb.	98 84 052	98 14 052	
	ISO	98 44 152	98 04 052	65 59 401
	Klemmverb.	98 84 152	98 14 052	
	ISO	98 44 252	98 04 052	65 59 407
	Klemmverb.	98 84 252	98 14 052	
	ISO	98 44 352	98 04 052	65 59 403
	Klemmverb.	98 84 352	98 14 052	
	ISO	98 44 552	98 04 052	65 59 404
	Klemmverb.	98 84 552	98 14 052	
	ISO	98 44 652	98 04 052	65 59 402
	Klemmverb.	98 84 652	98 14 052	
	ISO	98 44 752	98 04 052	65 59 409
	Klemmverb.	98 84 752	98 14 052	
ISO	98 44 952	98 04 052	65 59 406 und	
Klemmverb.	98 84 952	98 14 052	2 65 25 099	

# Conversion table from the current design to the new design

## HighTorque Servo Gearbox $a=80$



Ratio	Output shaft	Current Order-No.	New Order-No. Basic Gerbox	New Order-No. Motor flange
4,75	ISO	98 45 005	98 05 005	65 59 501
	Clamp connect.	98 85 005	98 15 005	
	ISO	98 45 105	98 05 005	65 59 503
	Clamp connect.	98 85 105	98 15 005	
	ISO	98 45 205	98 05 005	65 59 502
	Clamp connect.	98 85 205	98 15 005	
	ISO	98 45 405	98 05 005	65 59 507
	Clamp connect.	98 85 405	98 15 005	
	ISO	98 45 705	98 05 005	65 59 504
	Clamp connect.	98 85 705	98 15 005	
	ISO	98 45 805	98 05 005	65 59 505
	Clamp connect.	98 85 805	98 15 005	
	ISO	98 45 905	98 05 005	65 59 506
	Clamp connect.	98 85 905	98 15 005	
6,75	ISO	98 45 007	98 05 007	65 59 501
	Clamp connect.	98 85 007	98 15 007	
	ISO	98 45 107	98 05 007	65 59 503
	Clamp connect.	98 85 107	98 15 007	
	ISO	98 45 207	98 05 007	65 59 502
	Clamp connect.	98 85 207	98 15 007	
	ISO	98 45 407	98 05 007	65 59 507
	Clamp connect.	98 85 407	98 15 007	
	ISO	98 45 707	98 05 007	65 59 504
	Clamp connect.	98 85 707	98 15 007	
	ISO	98 45 807	98 05 007	65 59 505
	Clamp connect.	98 85 807	98 15 007	
	ISO	98 45 907	98 05 007	65 59 506
	Clamp connect.	98 85 907	98 15 007	
9,25	ISO	98 45 009	98 05 009	65 59 501
	Clamp connect.	98 85 009	98 15 009	
	ISO	98 45 109	98 05 009	65 59 503
	Clamp connect.	98 85 109	98 15 009	
	ISO	98 45 209	98 05 009	65 59 502
	Clamp connect.	98 85 209	98 15 009	
	ISO	98 45 409	98 05 009	65 59 507
	Clamp connect.	98 85 409	98 15 009	
	ISO	98 45 709	98 05 009	65 59 504
	Clamp connect.	98 85 709	98 15 009	
	ISO	98 45 809	98 05 009	65 59 505
	Clamp connect.	98 85 809	98 15 009	
	ISO	98 45 909	98 05 009	65 59 506
	Clamp connect.	98 85 909	98 15 009	
14,5	ISO	98 45 015	98 05 015	65 59 501
	Clamp connect.	98 85 015	98 15 015	
	ISO	98 45 115	98 05 015	65 59 503
	Clamp connect.	98 85 115	98 15 015	
	ISO	98 45 215	98 05 015	65 59 502
	Clamp connect.	98 85 215	98 15 015	
	ISO	98 45 415	98 05 015	65 59 507
	Clamp connect.	98 85 415	98 15 015	
	ISO	98 45 715	98 05 015	65 59 504
	Clamp connect.	98 85 715	98 15 015	
	ISO	98 45 815	98 05 015	65 59 505
	Clamp connect.	98 85 815	98 15 015	
	ISO	98 45 915	98 05 015	65 59 506
	Clamp connect.	98 85 915	98 15 015	

Ratio	Output shaft	Current Order-No.	New Order-No. Basic Gerbox	New Order-No. Motor flange
19,5	ISO	98 45 020	98 05 020	65 59 501
	Clamp connect.	98 85 020	98 15 020	
	ISO	98 45 120	98 05 020	65 59 503
	Clamp connect.	98 85 120	98 15 020	
	ISO	98 45 220	98 05 020	65 59 502
	Clamp connect.	98 85 220	98 15 020	
	ISO	98 45 420	98 05 020	65 59 507
	Clamp connect.	98 85 420	98 15 020	
	ISO	98 45 720	98 05 020	65 59 504
	Clamp connect.	98 85 720	98 15 020	
	ISO	98 45 820	98 05 020	65 59 505
	Clamp connect.	98 85 820	98 15 020	
	ISO	98 45 920	98 05 020	65 59 506
	Clamp connect.	98 85 920	98 15 020	
29	ISO	98 45 029	98 05 029	65 59 501
	Clamp connect.	98 85 029	98 15 029	
	ISO	98 45 129	98 05 029	65 59 503
	Clamp connect.	98 85 129	98 15 029	
	ISO	98 45 229	98 05 029	65 59 502
	Clamp connect.	98 85 229	98 15 029	
	ISO	98 45 429	98 05 029	65 59 507
	Clamp connect.	98 85 429	98 15 029	
	ISO	98 45 729	98 05 029	65 59 504
	Clamp connect.	98 85 729	98 15 029	
	ISO	98 45 829	98 05 029	65 59 505
	Clamp connect.	98 85 829	98 15 029	
	ISO	98 45 929	98 05 029	65 59 506
	Clamp connect.	98 85 929	98 15 029	
39	ISO	98 45 039	98 05 039	65 59 501
	Clamp connect.	98 85 039	98 15 039	
	ISO	98 45 139	98 05 039	65 59 503
	Clamp connect.	98 85 139	98 15 039	
	ISO	98 45 239	98 05 039	65 59 502
	Clamp connect.	98 85 239	98 15 039	
	ISO	98 45 439	98 05 039	65 59 507
	Clamp connect.	98 85 439	98 15 039	
	ISO	98 45 739	98 05 039	65 59 504
	Clamp connect.	98 85 739	98 15 039	
	ISO	98 45 839	98 05 039	65 59 505
	Clamp connect.	98 85 839	98 15 039	
	ISO	98 45 939	98 05 039	65 59 506
	Clamp connect.	98 85 939	98 15 039	
52	ISO	98 45 052	98 05 052	65 59 501
	Clamp connect.	98 85 052	98 15 052	
	ISO	98 45 152	98 05 052	65 59 503
	Clamp connect.	98 85 152	98 15 052	
	ISO	98 45 252	98 05 052	65 59 502
	Clamp connect.	98 85 252	98 15 052	
	ISO	98 45 452	98 05 052	65 59 507
	Clamp connect.	98 85 452	98 15 052	
	ISO	98 45 752	98 05 052	65 59 504
	Clamp connect.	98 85 752	98 15 052	
	ISO	98 45 852	98 05 052	65 59 505
	Clamp connect.	98 85 852	98 15 052	
	ISO	98 45 952	98 05 052	65 59 506
	Clamp connect.	98 85 952	98 15 052	

# Conversion table from the current design to the new design

## HighTorque Servo Gearbox $a=100$



Ratio	Output shaft	Current Order-No.	New Order-No. Basic Gerbox	New Order-No. Motor flange
4,75	ISO	98 46 005	98 06 005	65 59 501
	Klemmverb.	98 86 005	98 16 005	
	ISO	98 46 205	98 06 005	65 59 502
	Klemmverb.	98 86 205	98 16 005	
	ISO	98 46 305	98 06 005	65 59 507
	Klemmverb.	98 86 305	98 16 005	
	ISO	98 46 705	98 06 005	65 59 504
	Klemmverb.	98 86 705	98 16 005	
	ISO	98 46 805	98 06 005	65 59 505
	Klemmverb.	98 86 805	98 16 005	
ISO	98 46 905	98 06 005	65 59 506	
Klemmverb.	98 86 905	98 16 005		
6,75	ISO	98 46 007	98 06 007	65 59 501
	Klemmverb.	98 86 007	98 16 007	
	ISO	98 46 207	98 06 007	65 59 502
	Klemmverb.	98 86 207	98 16 007	
	ISO	98 46 307	98 06 007	65 59 507
	Klemmverb.	98 86 307	98 16 007	
	ISO	98 46 707	98 06 007	65 59 504
	Klemmverb.	98 86 707	98 16 007	
	ISO	98 46 807	98 06 007	65 59 505
	Klemmverb.	98 86 807	98 16 007	
ISO	98 46 907	98 06 007	65 59 506	
Klemmverb.	98 86 907	98 16 007		
9,25	ISO	98 46 009	98 06 009	65 59 501
	Klemmverb.	98 86 009	98 16 009	
	ISO	98 46 209	98 06 009	65 59 502
	Klemmverb.	98 86 209	98 16 009	
	ISO	98 46 309	98 06 009	65 59 507
	Klemmverb.	98 86 309	98 16 009	
	ISO	98 46 709	98 06 009	65 59 504
	Klemmverb.	98 86 709	98 16 009	
	ISO	98 46 809	98 06 009	65 59 505
	Klemmverb.	98 86 809	98 16 009	
ISO	98 46 909	98 06 009	65 59 506	
Klemmverb.	98 86 909	98 16 009		
14,5	ISO	98 45 015	98 06 015	65 59 501
	Klemmverb.	98 85 015	98 16 015	
	ISO	98 46 215	98 06 015	65 59 502
	Klemmverb.	98 86 215	98 16 015	
	ISO	98 46 315	98 06 015	65 59 507
	Klemmverb.	98 86 315	98 16 015	
	ISO	98 46 715	98 06 015	65 59 504
	Klemmverb.	98 86 715	98 16 015	
	ISO	98 46 815	98 06 015	65 59 505
	Klemmverb.	98 86 815	98 16 015	
ISO	98 46 915	98 06 015	65 59 506	
Klemmverb.	98 86 915	98 16 015		

Ratio	Output shaft	Current Order-No.	New Order-No. Basic Gerbox	New Order-No. Motor flange
19,5	ISO	98 46 020	98 06 020	65 59 501
	Klemmverb.	98 86 020	98 16 020	
	ISO	98 46 220	98 06 020	65 59 502
	Klemmverb.	98 86 220	98 16 020	
	ISO	98 46 320	98 06 020	65 59 507
	Klemmverb.	98 86 320	98 16 020	
	ISO	98 46 720	98 06 020	65 59 504
	Klemmverb.	98 86 720	98 16 020	
	ISO	98 46 820	98 06 020	65 59 505
	Klemmverb.	98 86 820	98 16 020	
ISO	98 46 920	98 06 020	65 59 506	
Klemmverb.	98 86 920	98 16 020		
29	ISO	98 46 029	98 06 029	65 59 501
	Klemmverb.	98 86 029	98 16 029	
	ISO	98 46 229	98 06 029	65 59 502
	Klemmverb.	98 86 229	98 16 029	
	ISO	98 46 329	98 06 029	65 59 507
	Klemmverb.	98 86 329	98 16 029	
	ISO	98 46 729	98 06 029	65 59 504
	Klemmverb.	98 86 729	98 16 029	
	ISO	98 46 829	98 06 029	65 59 505
	Klemmverb.	98 86 829	98 16 029	
ISO	98 46 929	98 06 029	65 59 506	
Klemmverb.	98 86 929	98 16 029		
39	ISO	98 46 039	98 06 039	65 59 501
	Klemmverb.	98 86 039	98 16 039	
	ISO	98 46 239	98 06 039	65 59 502
	Klemmverb.	98 86 239	98 16 039	
	ISO	98 46 339	98 06 039	65 59 507
	Klemmverb.	98 86 339	98 16 039	
	ISO	98 46 739	98 06 039	65 59 504
	Klemmverb.	98 86 739	98 16 039	
	ISO	98 46 839	98 06 039	65 59 505
	Klemmverb.	98 86 839	98 16 039	
ISO	98 46 939	98 06 039	65 59 506	
Klemmverb.	98 86 939	98 16 039		
52	ISO	98 46 052	98 06 052	65 59 501
	Klemmverb.	98 86 052	98 16 052	
	ISO	98 46 252	98 06 052	65 59 502
	Klemmverb.	98 86 252	98 16 052	
	ISO	98 46 352	98 06 052	65 59 507
	Klemmverb.	98 86 352	98 16 052	
	ISO	98 46 752	98 06 052	65 59 504
	Klemmverb.	98 86 752	98 16 052	
	ISO	98 46 852	98 06 052	65 59 505
	Klemmverb.	98 86 852	98 16 052	
ISO	98 46 952	98 06 052	65 59 506	
Klemmverb.	98 86 952	98 16 052		